

INDUS

NEVA MANUAL

THE **SMART WAY** TO HANDLE
BIGBAGS IN YOUR **ENTIRE** SUPPLY
CHAIN.

WWW.INDUS-BULKLOGISTICS.COM


Nijverheidsbuurt 15 | 3474 LA Zegveld, The Netherlands

+31(0)172 72 71 69 | info@indus-bulklogistics.com





Place the bottom part of the Indus Neva System on a flat, stable and hard surface



Position the 4 stacking poles of the Indus Neva system in the conical openings at the corners of the dek.



The Indus Neva System is now ready for positioning the Big Bag/FIBC.



Position the empty Big Bag /FIBC or place the already filled Big Bag in the system by lifting the filled big bag above the empty system with a forklift.



Attach the 4 lifting loops of the Big Bag/FIBC to the springhead.



The Indus Neva System is now ready for use.



Movement of Indus Neva Systems by a forklift truck (max. 2 x 1.500 kg.)



Stacked storage Indus Neva Systems (max. 4 x 1.500 kg.)



Bottom discharge with dosage and cut off possibility through the slide of the Indus Neva System



Storage of Indus Neva Systems if not in use or at return transport.